



Configuration of Nokia Ngage to Access Mi World on GPRS

1. Press the **Menu** button. Scroll to **Media** and select **Services**.

2. Go to Default access point and choose New access point. Select use default settings.



3. Under **Connection Name**, key in **MiWorld GPRS**.
Move down to **Data bearer** and press for options and select Change.
Choose **GPRS**.
Move down to **Access point name** and key in **miworld**
Then move down to **User name** and key in **+65XXXXXXXX** (where the last 8-digits is your mobile number).
Move on down to **Prompt password** and select **No**.
Go to **Password** and key in **user123**
Go to **Gateway IP address** and key in **172.016.001.023**
Move down to **Homepage** and key in <http://wap.miworld.com.sg>



4. To launch and access MiWorld Mobile, go to Services and select MiWorld GPRS to connect.
